

Thank you for purchasing Dermalogic Massage Oil / Lotion Warmer.
Please read all instructions carefully prior to operating the unit.

PRODUCT:

The warmer unit is beautifully crafted in wood laminated finish with brushed SS trim cover. The bottle is constructed from polished aluminum and comes with durable brushed SS pump for long lasting professional use at salons, spas, clinics and homes.

SPECIFICATION:

Model No: KDA-OLAPP-40
Warmer Dimension: 3.75" x 3.75" x 7.25"
Bottle Dimension: Diameter 2" x 8.7"
Bottle Capacity: 8.5 oz (265ml)
Voltage: 110/120V, 50/60Hz
Power: 40W
Temperature: 140°F (60°C)



OPERATIONS STEPS:

1. Make sure that the warmer unit is placed on a flat surface prior to turning on the power
2. Fill the bottle with desired massage oil or lotion then place the filled bottle inside the heating chamber.
3. Press "Power" switch and the light indicator will come on to indicate that the unit is working.
4. The following is an approximate time it would take to reach the indicated temperature initially from normal room temperature. Therefore, confirm the desired temperature prior to application.

Time	Temperature (°F)	Temperature (°C)
15 Min	108 °F	42 °C
30 Min	122 °F	50 °C
45 Min	130-140 °F	55-60 °C

5. The warmer unit will heat up bottle to max 140°F and maintain at this temperature when the power is turned on.
6. After use, turn off and unplug unit for safety.

CAUTION:

- Never operate the unit if the electrical cord or plug is damaged.
- Do not operate this machine in an extremely cold environment.
- Do not operate unit if wet or accidentally placed in the water.
- Do not move unit while in operation and unplug the unit when not in use.
- Allow to cool before handling, cleaning, and storing.
- The aluminum bottle surface may get dented if dropped or hit with high impact force.
- The unit is to be repaired by qualified technician only when found to be defective, otherwise will void any warranty.
- KEEP UNIT OUT OF THE REACH OF CHILDREN.

CONTACT US

☎ 972-926-6488

✉ service@aycllc.com

🌐 www.aycllc.com